

PORTAMATRICULAS HONDA CBR600RR 03' -06'
LICENSE SUPPORT HONDA CBR600RR 03' -06'

REF:1612



INSTRUCCIONES DE MONTAJE

- 1- Desmontar el portamatriculas original (Para facilitar la operación es aconsejable desmontar en primer lugar la base sillin trasera y la delantera. A continuación sacar el colin que va fijado con cuatro tornillos).
- 2- Montar los soportes laterales usando los tornillos allen M6x10(posiciones 3 y 4). Los intermitentes deben montarse en la posición 5. Se suministran dos bridas de plástico para fijar el cable del intermitente en el agujero 6. Montar a continuación el soporte central usando los tornillos hexagonales de M6x10 (2) y las tuercas M6(1). Ajustar los laterales mediante la regulación que ofrece el conjunto y apretar.

INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original license support (in order to make easy the assembling process we recommend to dismount the front and rear seat base. Next, take off the seat that is fixed with four fasteners).
- 2- Mount the side supports using the M6x10 allen screws (positions 3 and 4). The turn signals must be mounted on position 5. It is supplied two plastic bridles to fix the turn signal cable in the drill 6. Mount next the central support using the M6x10 hexagonal screws (2) and the M6 nuts (1). Adjuts the side supports through the regulation that the group offer, and tighten them all.

Material suministrado para el montaje en la motocicleta:

Material supplied to assemble the license support:

DENOMINACIÓN		CANTIDAD
Tornillo M6x10 DIN6921	<i>M6X10 screw DIN6921</i>	2
Tuerca M6 grafilada DIN6923	<i>M6 Nut DIN 6923</i>	2
Tornillo Allen M6x10 DIN1001	<i>M6x10 allen screw DIN 1001</i>	4
Bridas de plástico 2,5x98	<i>2.5x98 plastic bridles</i>	2
Soportes c\negro	<i>Support c\nblack</i>	3
Catadrioptico	<i>Reflector</i>	1
Soporte Catadrioptico	<i>Support for reflector</i>	1

