

REF.20220N

PROMOTER KIT

INSTRUCTION FOR USE



CLEAN THE SURFACE WITH NATURAL SOAP





APPLY THE PEN ONLY ON SPOILER SUPPORT PIECE AREA

CHECK IS COMPLETLY DRY BEFOR START